

INSTALLATION GUIDE

ROMAN BLINDS

Showroom
22A Liddiard Street
Hawthorn VIC 3122

p +613 9819 1484
m +614 0284 1310
f +613 8677 1179

Thank you for purchasing a Roman blind. Your new blind has been custom built for you from the highest quality materials.

Thank you for purchasing this fine window treatment proudly constructed by us. Your blind has been custom made to your personal specifications with the highest standards of quality and craftsmanship. We have confidence that it will provide you with many years of beauty and easy maintenance. Enjoy!

Follow the easy 'step by step' instructions to install your blind. Should you need additional support, please feel free to call our Customer Service Center at 03 9819 1484 or e-mail us at info@arrowcurtains.com.

We will be glad to help you. Again, we appreciate that you have chosen us to enhance the design and look of your home.


- 1** Measure 150mm from the ends of the headrail and mark the bracket locations on the mounting surface.
- 2** Space additional brackets evenly between the end brackets.
- 3** Ensure the brackets do not interfere with the inner workings of the blind.



- 4** Mark the screw holes with a pencil.
- 5** Drill a small pilot hole in the middle of each marking.
- 6** Fix the brackets to the frame with the screws provided.



- 7** Carefully place the Roman Blind on top of the architrave and brackets, slide the blind across so that it is even on both sides and screw through the bracket into the underside of the head rail.
- 8** Attach the cord cleat at a height where it will be out of reach for children.
- 9** Once the cleat is mounted, simply wrap the excess cord around the cleat after each use of the Roman Blind.



OPERATE THE ROMAN BLIND

To raise the blind hold the cord and pull until the blind is at the desired height.

To lower the blind, holding the cord, let the blind lower to the desired level.

HOW TO OPERATE A CORD LOCK ROMAN

To raise the roman, hold the roman and pull until the blind is at the desired height. pull the cord towards the outside of the blind to lock into position. To lower the roman pull towards the inside of the blind to unlock.

holding the cord, let the blind lower to the desired level. move the cord to the outside to lock.

CARE AND CLEANING

ROMAN blinds are made of antistatic, dust resistant fabrics which repel dirt and dust. For most fabrics, the following

options are available if your roman needs cleaning.

Dusting regular light dusting with a feather duster is all the cleaning that is needed in most circumstances.

Remove marks by sponging gently with mild detergent in luke warm water.